# Minimate Pro6<sup>™</sup>

# Series IV – Advanced Vibration, Overpressure and Sound Monitors

6 - Channel data acquisition for the following range of Applications:

- Blast monitoring for compliance
- Multi-point monitoring
- Remote monitoring -Auto Call Home™
- Blast analysis
- Near and Farfield blast analyis
- Pile driving
- Construction activity
- Demolition activity
- Structural monitoring
- Underwater monitoring
- Heavy Transportation

The Instantel® Minimate Pro6<sup>TM</sup> vibration, overpressure and sound monitors are built on the success of the Minimate® Series III monitoring systems.

The **Minimate Pro6** offers 64MBs of memory, improved ruggedness, including a metal case and connectors, and water resistance

Connect two standard ISEE or DIN Triaxial Geophones to monitor vibration sources from two different locations. Or, connect one ISEE or DIN Triaxial Geophone and an ISEE Linear Microphone or optional Sound Microphone when air overpressure or sound data is required.

#### **Versatile**

Each compliance sensor's calibration date, serial number, and sample rate specification are determined by the Sensor Check feature of the unit and stored in the setup file. The sensor type, calibration date and serial number are also recorded on the Event Report.

For those challenging monitoring applications, such as tunneling, the **Series IV** units include EMI shielding and built-in noise and anti-aliasing filters; both the sensor and auxiliary channels are isolated.

With the optional **Instantel Blastware**® **Advanced Module** perform VDV monitoring, Signature Hole Analysis, and real time display of Histogram data.

#### **Intelligent**

View Peak Vibration and Zero Crossing Frequencies immediately after each Event occurs. Toggle between Peak Vibration and Peak Overpressure with a simple push of a button. Data highlights including Operator, Trigger, Duration, and Maximum Vibration and Overpressure are also available for review, right on the monitors display.

# **Remote Monitoring**

For remote installations, the **Instantel Auto Call Home** feature will automatically transfer event files from field to office as they are recorded using a variety of wireless modems. From there, the **Blastware Mail** feature of the **Instantel Blastware** software automatically distributes files or summary information to multiple e-mail addresses.



### Vision™

**Auto Call Home** integrates with **Vision**, Instantel's Cloudbased vibration monitoring data hosting application (optional). With **Vision**, you can store monitoring data securely in the Cloud and deliver the information your stakeholders need—anytime, anywhere, instantly. Vision also lets you:

- View, sort, filter and print event data to identify trends before they become issues.
- Map your site—using technology from Google, you can place your monitoring units on a street or satellite map.
- Upload photos for a record of the latest progress.

#### Easy to use

Even with all of these features, the **Minimate Pro6** system is still easy for anyone to use. A high-contrast LCD and ten-key tactile keypad drives simple menu operations, while graphic icons indicate battery and memory levels at a glance.

## **Key Features**

- Dedicated function keys and intuitive menu-driven operation enable quick and easy setup.
- Sample rates from 512 to 65,536 S/s per channel, independent of record times.
- Continuous monitoring means zero dead time between events, even while the unit is processing.
- Instantel Histogram Combo<sup>TM</sup> mode allows capturing thousands of full waveform records while simultaneously recording in histogram mode.
- The Auto Call Home feature automates remote monitoring applications.
- Non-volatile memory with standard 7,100-plus event storage capacity.
- Records full waveform events over two hours long.
- Match any channel with a variety of sensors; geophones, accelerometers, hydrophones and a microphone channel.
- Optional Sound Microphone available for sound monitoring. Combine an ISEE or DIN Triaxial Geophone with the Sound Microphone to monitor two types of event data.



# **General Specifications**

# **Minimate Pro6**

Minimate Pro6 Channels

Channels 1-3, ISEE (or DIN) Triaxial Geophone, and

Vibration Monitoring

Range

Response Standard Resolution

Accuracy (ISEE / DIN)

Transducer Density

Frequency Range (ISEE / DIN) Maximum Cable Length (ISEE / DIN)

Air Overpressure Monitoring

Weighting Scales Response Standard Linear Range Linear Resolution Linear Accuracy

Linear Frequency Response

Cable Length

Optional Advanced Sensors

Channels 4-6, a second ISEE (or DIN) Triaxial Geophone, or an ISEE Linear Microphone

Up to 254 mm/s (10 in/s)

ISEE Seismograph Specification or DIN 45669-1

0.00788 mm/s (0.00031 in/s)

 $\pm$  5% or 0.5 mm/s (0.02 in/s), whichever is larger, between 4 and 125 Hz / DIN 45669-1 standard

2.13 g/cc (133 lbs/ft<sup>3</sup>)

2 to 250 Hz, within zero to -3 dB of an ideal flat response / 1 to 315 Hz or 1 to 80 Hz

75 m (250 ft) / 1,000 m (3,280 ft)

ISEE Linear Microphone

ISEE Seismograph Specification 88 to 148 dB (500 Pa [0.072 psi] Peak)

0.0156 pa (2.2662×10-6 psi)

+/- 10% or +/- 1 dB, whichever is larger, between 4 and 125 Hz

2 to 250 Hz between -3 dB roll off points

75 m (250 ft)

Contact Instantel for more information Sound Level Microphone, High Pressure Microphone, High Frequency Geophone, Uniaxial and Triaxial

Accelerometer, and Hydrophone

#### Waveform Recording

Record Modes Waveform, Waveform Manual 0.13 to 254 mm/s (0.005 to 10 in/s) Seismic Trigger Linear Acoustic Trigger 2.0 pa to 500 pa (100 dB to 148 dB)

Sample Rate 512, 1,024, 2,048, 4,096, 8,192, 16,384, 32,768, 65,536 S/s per channel (independent of record time)

Fixed record time, Instantel AutoRecord™ record stop mode Record Stop Mode

1-9,000 seconds (1-30 seconds, then 30-second increments up to 150 minutes) plus a 0.25 second pre-trigger Record Time Event is recorded until activity remains below trigger level for duration of auto window, or until available AutoRecord Time

memory is filled.

Cycle Time Recording uninterrupted by event processing, monitoring, or communication - no dead time below 65 KHz.

64 MBs. Optional 240 MBs.

Full Waveform Events 7,100-plus 1 second events at 1,024 S/s sample rate with two geophones

### Histogram Recording

Minimate Pro6 Storage Capacity

Histogram and Instantel Histogram Combo™ (monitor captures triggered waveforms while Record Modes

recording in Histogram mode)

Recording Interval 1 to 30 seconds at 1 second intervals, and 30 seconds to 60 minutes at 30 second intervals 512,000 intervals, examples: 11.9 days at 2 second intervals, or 355 days at 1 minute Histogram Storage Capacity

Histogram Combo Storage Capacity Example: 30 days of Histogram recording at 1 minute intervals, and over 6,500 1 second waveform events

#### **Physical Specifications**

Dimensions Unit Weight Battery

User Interface Display PC Interface

Auxillary Inputs and Outputs Environmental

LCD Operating Temperature Electronics Operating Temperature

Water Resistance Remote Communications

Additional Features

Electrical Standards

25.4(l) x 11.75(w) x 10.80(h) cm (10.00 x 4.63 x 4.25 in); length dimension includes connectors and dust caps 2.27 kg (5 lbs)

10 Days

10 domed tactile with separate keys for common functions 7-line x 32-character, high-contrast, multi-color backlit LCD

Ethernet® cable, supplied, for PC to unit connection (Auto Call Home is not supported over Ethernet), or

RS-232 with an optional USB adapter External Trigger and Remote Alarm

-20 to 45 °C (-4 to 113 °F) -40 to 45 °C (-40 to 113 °F)

IP67 – submerse to 30 cm (1 ft.) for 24 hours Instantel approved serial communication modems

Automatically transfers events when they occur through the Instantel Auto Call Home feature

Monitor start/stop timer

(Optional) Vision provides you and your stakeholders with secure, encrypted, Cloud-based access to the data they need, providing instant sharing for time-sensitive projects.

CE Class B

Corporate Office: 309 Legget Drive, Ottawa, Ontario K2K 3A3 Canada

US Office:

808 Commerce Park Drive, Ogdensburg, New York 13669 Toll Free: (800) 267 9111 Telephone: (613) 592 4642 Facsimile: (613) 592 4296 Email: sales@instantel.com



© 2015 Xmark Corporation. Instantel, the Instantel logo, Auto Call Home, AutoRecord, Blastmate, Blastware, Histogram Combo, InstaLink, and Minimate are trademarks of Stanley Black & Decker, Inc., or its affiliates.